

For HID Beloader Pro version users, please follow the steps below:

1: Use [HID Manager 1.0](#) to upgrade the firmware [Beloader Pro 20230303.1745](#)

2: After the upgrade is successful, remove the Beloader Pro, and then plug it into the PC (do not press the upgrade button) , after 5 seconds, then unplug.

3: [Download HID Manager 2.0](#) , unzip and run it.



4: Beloader Pro enter the update mode(hold update button and insert), then you can use HID Manager 2.0 to update and config.

5: Remove Beloader Pro, and use it normally.

Please refer to [the video](#) for the steps to connect Cronus Zen. The Zen set should:

☐ Enable PS4 Speciality (For PS5 Console)

☒ Enable PS Remote Play (For PS5/PS4 Consoles or PC)

Emulator Output Protocol: PLAYSTATION 4/5 ▾ Mirror Running

A Console/PC is detected. It's not recommended to change this.

Remote Slot Change: DISABLE ▾



Factory Reset



Erase Memory
Slots



Device Monitor



Find Device



Reset Device



Clear BT Devices

MOUSE

JOYPAD



CONSOLE

