


For **HID Beloader Pro version** users, please follow the steps below:

1: Download the firmware [Beloader Pro 20230310.1200](#) and unzip it.

2: [Download HID Manager 2.0](#) , unzip and run it.



3: Beloader Pro enter the update mode(hold update button and insert), then you can use HID Manager 2.0 to update and config.

4: Remove Beloader Pro, and use it normally.

Please refer to [the video](#) for the steps to connect Cronus Zen. The Zen set should:

☐ Enable PS4 Speciality (For PS5 Console)

☒ Enable PS Remote Play (For PS5/PS4 Consoles or PC)

Emulator Output Protocol: PLAYSTATION 4/5 ▾ Mirror Running

A Console/PC is detected. It's not recommended to change this.

Remote Slot Change: DISABLE ▾



Factory Reset



Erase Memory
Slots



Device Monitor



Find Device



Reset Device



Clear BT Devices

MOUSE

JOYPAD



CONSOLE

