


Config and Update with Manually way

A: Uninstall Beloader Pro driver if you install it before. Here is the uninstall way:



B: After uninstall successfully, do as following way:

- 1: Hold Beloader Pro update button and insert into PC, you will find update disk.
- 2: Run PSN Account-ID Tool to get Account ID.
- 3: Open **PSN Config** text file from update disk, input the Account ID and PIN into it and save, the Pin is 8 digital on PS5 system.
- 4: Remove beloader pro from PC and insert into PS5 or other USB power adapter.

PSN Account-ID获取工具

登录PSN

click here to
PSN web

若网页显示“redirect”则表示登录成功
请把成功时的链接粘贴到下面
再点击获取按钮

copy the full link to here after you see
redirect

获取PSN AccountID

click here to get ID

获取结果

->等待获取中

you will find ID here and copy it

If user get problem still, please contact us bbsbeloader@163.com or tell us from forum.